

Unit Information





220-240V – 50/60Hz – 400W
(on units after 5/8/2015)
230V – 50Hz – 375W

WARING COMMERCIAL®

Europe Variable Speed Blenders

LB20EG / glass container

LB20ES / stainless steel container









003548
Blending Assembly
500758
Stainless Steel Container
with Blending Assembly
008065
Stainless Steel Container
with Blending Assembly
and Vinyl Lid



Base Unit Components

LB20EG

LB20ES



Catalog

LB20EG

LB20ES

(on units after 5/8/2015) (on units after 4/6/2001)

220-240V – 50/60Hz – 400W 230V – 50Hz – 375W

Model

Same

38BL67

Waring Factory Service Center**314 Ella T. Grasso Ave.****Torrington, CT 06790****Tele. 1-800-269-6640****Fax 860-496-9017****www.waringcommercialproducts.com**

Illustration #	Part #	Description
1	003146	Center Lid
2	003574-09	Outer Lid <i>(changed after 3/13/2007)</i>
3	003504	Cap Nut
4	024204	Blade <i>(changed after 7/11/2006)</i>
5	003503	Bearing Cap
6	003508	Fairprene Washer
7	010012	Bearing Holder
8	009724	Nylon Washer
9	003537	Stainless Steel Washer (3 required)
10	003509	Neoprene Washer (4 required)
11	003510	Bakelite Washer
12	003500	Drive Shaft
13	009780	Hex Nut
14	003573	40 oz. Glass Container (5 cups)
15	011700	Center Lid <i>(on units after 8/11/2011)</i>
	003146	Center Lid
16	013443	Round Outer Lid
17	012860	32 oz. Stainless Steel Container
18	009762	Gasket
19	015055	Container Adapter
20	503473	Drive Coupling Assembly <i>(on units after 9/9/2016)</i>
	002518	Drive Coupling Assembly
21	003498	Jar Pad (4 required)
22	018996	Jar Holder
23	035411	Screw (4 required <i>on units after 9/9/2016</i>)
	012370	Screw (4 required)
24	035357	Upper Spacer <i>(on units after 5/8/2015)</i>
	016610	Half Baffle (2 required)
25	017283	Plated Motor Bracket
26	033787	Sems (4 required <i>on units after 3/23/2017</i>)
27	035339	Housing Seal <i>(on units after 9/9/2016)</i>
	019936	Housing Seal
28	035058	Chiaphua Motor <i>(on units after 5/8/2015)</i>
	026536	ECM Motor <i>(on units after 5/5/2009)</i>
	024147	ECM Motor <i>(changed after 6/5/2001)</i>
29	019943	Base
30	002676	Spacer (4 required <i>on units after 9/9/2016</i>)

Catalog

LB20EG

LB20ES

(on units after 5/8/2015)

220-240V – 50/60Hz – 400W

Model

Same

(on units after 4/6/2001)

230V – 50Hz – 375W

38BL67

Waring Factory Service Center**314 Ella T. Grasso Ave.****Torrington, CT 06790****Tele. 1-800-269-6640****Fax 860-496-9017****www.waringcommercialproducts.com**

Illustration #	Part #	Description
31	002881	Kep Nuts (4 required <i>on units after 5/8/2015</i>) (1 required <i>on units after 4/11/2001</i>) (6 required)
32	502735	Toggle Switch Assembly <i>(on units after 6/5/2001)</i>
	502219	Toggle Switch Assembly
33	014604	Lock Washer
34	016236	Hex Nut <i>(changed after 3/10/2010)</i>
35	019394	Speed Control with Potentiometer
36	010955	Washer (4 required)
37	019181	Screw (4 required)
38	035920	Capacitor Assembly <i>(on units after 9/9/2016)</i>
39	502737	4" Black Lead Assembly (3 required)
40	502767	6" Brown Lead Assembly <i>(on units after 5/8/2015)</i>
41	503505	6" Blue Lead Assembly <i>(on units after 9/9/2016)</i>
	502738	6" Blue Lead Assembly
42	502763	Resistor Assembly <i>(on units after 5/8/2015)</i>
43	501658	10" Green-Yellow Lead Assembly (2 required <i>on units after 9/9/2016</i>)
	501658	10" Green-Yellow Lead Assembly <i>(on units after 5/8/2015)</i>
44	035893	EMI Filter <i>(on units after 9/9/2016)</i>
	503475	EMI Filter Assembly <i>(on units after 5/8/2015)</i>
	502448	EMI Filter Assembly
45	015097	Hex Nut (1 required <i>on units after 4/4/2017</i> - 2 required)
46	019181	Screw (1 required <i>on units after 4/4/2017</i> - 2 required)
47	019123	Large Crimp Connector (2 required <i>on units after 9/9/2016</i>)
	019123	Large Crimp Connector (2 required <i>on units after 5/8/2015</i>)
	012409	Small Crimp Connector (2 required <i>on units after 5/8/2015</i>)
	012409	Small Crimp Connector (4 required <i>on units after 2/12/2009</i>)
	012409	Small Crimp Connector (3 required)
48	013731	Cable Tie (5 required)
49	002943	Washer (4 required <i>on units after 9/9/2016</i>)
	002943	Washer (2 required <i>on units after 5/8/2015</i>) – (3 required)
50	027278	Ground Screw (2 required <i>on units after 5/8/2015</i>)
	013659	Screw (2 required <i>on units after 4/11/2001</i>)
	018317	Screw (2 required)
51	016042	Washer (2 required <i>on units after 3/25/2003</i>) – (3 required)
52	013680	Strain Relief
53	502782	Cord Set <i>(on units after 4/4/2017)</i>
	503476	Cord Set <i>(on units after 5/8/2015)</i>
	501842	Cord Set

Catalog

LB20EG

LB20ES

(on units after 5/8/2015) (on units after 4/6/2001)
220-240V – 50/60Hz – 400W 230V – 50Hz – 375W

Model

Same

38BL67

Waring Factory Service Center

314 Ella T. Grasso Ave.

Torrington, CT 06790

Tele. 1-800-269-6640

Fax 860-496-9017

www.waringcommercialproducts.com

Illustration#	Part#	Description
54	035386	4 A Fuse Cartridge (on units after 3/3/2016)
55	035186	Fuse Holder (on units after 3/3/2016)
56	503503	9" Blue Lead Assembly
57	503504	6" Brown Lead Assembly
58	503506	6" Green-Yellow Lead Assembly
59	900243	Insulating Tape (on units after 3/16/2018)
	035989	Channel Baffle Guard (on units after 4/4/2017)
60	502736	Bottom Plate with Screen
61	503376	Foot & Screw Assembly (3 required on units after 6/28/2010)
	002891	Foot (3 required uses 003569 screw NO Longer Available use 503376)
62	019270	Potentiometer Knob
63	025665	Increments Overlay
64	023052	Name Plate

Parts No Longer Used

 **024377** - Insulating Sleeve

(last used on 4/23/2015)

 **014603** - Locking Ring

(last used 5/8/2015)

 **018455** - Reset Switch
(Obsolete)

 **015184** - Hex Nut

(last used 5/8/2015)


 **010955** - Washer (2 required with EMI Filter)
(last used 9/9/2016)

 **002644** - Square Drive Stud
 **003507** - Washer
 **003514** - Slinger
 **002882** - Coupling
002518 Drive Coupling
(parts that can be purchased separately)
(last used 9/9/2016)


 **016610** - Baffle
(2 required)
(last used 5/8/2015)

 **012370** - Screw
(4 required)
(last used 5/8/2015)

 **012369** - Kep Nut
(4 required)
(last used 5/8/2015)

 **026536** ECM Motor
(last used 5/8/2015)

 **005240** - Screw
(4 required)
(last used 5/8/2015)



Catalog

LB20EG

LB20ES

(on units after 5/8/2015)

(on units after 4/6/2001)

220-240V – 50/60Hz – 400W

230V – 50Hz – 375W

Model

Same

38BL67

Waring Factory Service Center


314 Ella T. Grasso Ave.

Torrington, CT 06790

Tele. 1-800-269-6640


Fax 860-496-9017

www.waringcommercialproducts.com




Wiring Diagram

(on units after 5/8/2016)



Wiring Diagram

(on units after 2/12/2009)



Wiring Diagram