





1	T055413
1	T055452
2	T055457
2	T065454
3	T065445
4	Q031322
5	T065447
6	Q221338
7	T065446
8	T065460
9	T065461
s/n	T065462
10	X165400
10	R185431
	Q152004
	Q221342
11	T055405
12	H015404
	Q152004
	Q221342
13	T035405
	Q012031
	Q221342
14	T035404
	Q419005
15	T052603
	Q419005
16	H015400
16	H025400
	Q419005
17	Q221343
18	Q151336
19	X162667
19	R162613
	Q221342
	Q152004
20	H012802
20	H022802
	Q221342
	Q152004
21	T052608
	Q419005
22	R221345
23	R162810
24	H012805
	Q242030
	Q162030
25	U652651
25	H022604
	Q419005
26	U652606
	Q221023
27	H012809
27	H012804
	Q419005
28	H012808
29	H012806
	Q419005

30	U652640
31	U325611
	Q419005
32	H012602
32	H022602
	Q419005
33	Z20106
34	Q221345
35	R162812
36	R152811
36	R162813
	Q419005
37	H012603
37	H022603
	Q419005
38	H012606
38	H022606
	Q302022
	Q242030
	Q162030
39	X010503
	Q419007
40	T055424
	Q221342
	Q302022
	Q012031
41	H015403
	Q012031
	Q221342
42	H015402
	Q419005
43	H025402
44	T055442
s/n	T055425
45	R205429
45	R205428
	Q419005
46	R205425
47	H015405
47	H025403
48	T065400
	Q419005



1	Q223019
2	U112401
2	T011600
2	9424500
3	H015013
4	Q419005
5	T052603
6	Q012031
7	U322116
	U442138
	U442137
8	U442133
9	X012101
10	U222130
11	Q221342
12	Q012031
13	Q162030
14	H015010
15	Q221324
16	Q306027
17	S112804

18	Q306055
19	U542101
20	R613030
21	U333003
22	S113034
23	Q152004
24	Q221342
25	H015008
25	H025003
	Q302022
	Q162030
26	U/02101
27	U635008
28	Q306061
29	Q221336
30	U055043
31	H015014
32	U322109
33	U265026
34	U325707
35	Q012031
36	Q152004

37	Q419005
38	T035404
39	T055701
40	Q302022
41	Q162030

		BUTANO - PROPANO
2	U112401	Tobera Ø 1,55
7	U442138	Injector piloto Ø 0,25
		GAS NATURAL
2	1011600	Tobera Ø 2,25
7	U442137	Injector piloto Ø 0,40
		GAS VILLA
2	9424500	Tobera Ø 5,35
7	U442138	Injector piloto Ø 0,25

		BUTANO - PROPANO
2	R302400	Tobera Ø 1,65
7	U442138	Injector piloto Ø 0,25
		GAS NATURAL
2	U112403	Tobera Ø 2,65
7	U442137	Injector piloto Ø 0,40
		VARIOS
s/n	H016515	Folleto de instrucciones