


SPARE PARTS LIST



SPARE PARTS LIST

SPARE PARTS LIST LEVAC 4N (AVM4)					
No. Part	Code Part	Description	Validity start date	Validity end date	Notes
1	1600483	CONTROLS STICKER LEVAC 4N	01/01/1900	31/12/2099	
2	1602879	COMMAND BOARD D031.0	01/01/1900	31/12/2099	
3	1604098	TRANSFORMER 200VA 230/10-12-16V	01/01/1900	31/12/2099	
4	1604088	POWER BOARD L056 230V	01/01/1900	31/12/2099	
5	1604081	VACUUM PUMP CP30 230V/50HZ	01/01/1900	31/12/2099	
6	1601815	VACUUM PUMP EXHAUST FILTER CP30/EVP30	01/01/1900	31/12/2099	
7	1604047	SEALING BAR L=466 VACUUM 2009/LEVAC 4N	01/01/1900	31/12/2099	
8	1602292	SILICONE SEAL(2PCS)+SILICONE RUBBER VACUUM2009/VACUUM2010	01/01/1900	31/12/2099	
9	1604108	UPPER VACUUM CHAMBER	01/01/1900	31/12/2099	
10	1604059	SOLENOID VALVE 1/8" FF D2 NBR 230V	01/01/1900	31/12/2099	
11	1604072	SWITCH CONTACT	01/01/1900	31/12/2099	
12	1604110	LEFT + RIGHT BLACK LEVER	01/01/1900	31/12/2099	
13	1604048	POWER CABLE 3X1X2300 SHUKO EUR	01/01/1900	31/12/2099	
14	1604107	UPPER COMPLETE VACUUM CHAMBER SET	01/01/1900	31/12/2099	
15	1604074	STOPPER AND FILTER	01/01/1900	31/12/2099	
16	1604408	D=4X6 HOSE (5 MT)	01/01/1900	31/12/2099	
17	1604409	D=6X9 HOSE (5 MT)	01/01/1900	31/12/2099	
18	1604082	VACUUM SENSOR SIGNAL LUX 693MBAR	01/01/1900	31/12/2099	