



Fine Porcelain



2018 Serving Dishes and Accessories



Dish 3.25"x1.5" | 8.5x4 cm

Inner box: 12 pcs
Outer carton: 288 pcs




Dish 3.25"x2.25" | 8.5x6 cm

Inner box: 12 pcs
Outer carton: 288 pcs




Dish 4"x1.5" | 10x4 cm

Inner box: 12 pcs
Outer carton: 288 pcs




Dish 2" | 5 cm

Inner box: 12 pcs
Outer carton: 288 pcs




Dish 2.75"x2.25" | 7x6 cm

Inner box: 12 pcs
Outer carton: 288 pcs





Dish 2.25"x2.25" | 6x6 cm

Inner box: 12 pcs
Outer carton: 192 pcs




Dish 1.75"x1.75" | 4.5x4.5 cm

Inner box: 12 pcs
Outer carton: 288 pcs

Dish 3.25" | 8 cm

Inner box: 12 pcs
Outer carton: 144 pcs




Sauce Dish 3"x2" | 8x5 cm

Inner box: 12 pcs
Outer carton: 192 pcs




Sauce Dish 3"x2.25" | 8x5.5 cm

Inner box: 12 pcs
Outer carton: 192 pcs




Dish 3"x2.75" | 7.5x7 cm

Inner box: 12 pcs
Outer carton: 144 pcs




Dish 3"x2.75" | 8x7 cm

Inner box: 12 pcs
Outer carton: 288 pcs




Dish 3.75"x2.25" | 9.5x5.5 cm

Inner box: 12 pcs
Outer carton: 144 pcs




Dish 3.5"x3.5" | 9x9 cm
5 fl oz | 140 ml

Inner box: 6 pcs
Outer carton: 96 pcs




Dish 5" | 13 cm

Inner box: 6 pcs
Outer carton: 96 pcs




Dish 4.25"x4" | 11x10.5 cm

Inner box: 12 pcs
Outer carton: 144 pcs




Dish 4.75"x3.25"x2" | 12x8x5 cm

Inner box: 6 pcs
Outer carton: 96 pcs




Dish 3.75"x2.5"x1.5" | 9.5x6.5x4 cm

Inner box: 12 pcs
Outer carton: 144 pcs




Dish 3"x2"x1.25" | 8x5.5x3 cm

Inner box: 12 pcs
Outer carton: 192 pcs




Bowl 6" | 15 cm, 15 fl oz | 450 ml

Inner box: 6 pcs
Outer carton: 48 pcs




Dish 3.25"x2 | 8.5x5 cm

Inner box: 12 pcs
Outer carton: 288 pcs



Dish 3.25"x2" | 8x5 cm

Inner box: 12 pcs
Outer carton: 288 pcs



Dish 3.75"x3" | 9.5x7.5 cm

Inner box: 12 pcs
Outer carton: 144 pcs



Dish 4.25"x2.75" | 11x7 cm

Inner box: 12 pcs
Outer carton: 144 pcs



Dish 3.25"x2 | 8x5 cm

Inner box: 12 pcs
Outer carton: 144 pcs



Dish 6"x3.5" | 15.5x9 cm

Inner box: 6 pcs
Outer carton: 96 pcs



Dish 4"x3" | 10.5x7.5 cm

Inner box: 12 pcs
Outer carton: 144 pcs



Dish 3"x2.25" | 8x5.5 cm

Inner box: 12 pcs
Outer carton: 192 pcs



Snack Dish 3.75"x2.75" | 9.5x7 cm

Inner box: 12 pcs
Outer carton: 144 pcs



Snack Dish 3.75"x2.75" | 9.5x7 cm

Inner box: 12 pcs
Outer carton: 144 pcs



Snack Dish 3.75"x2.75" | 9.5x7 cm

Inner box: 12 pcs
Outer carton: 144 pcs



Snack Dish 3.5"x2.75" | 9x7 cm

Inner box: 12 pcs
Outer carton: 144 pcs



Dish 4"x2.5"x1.25" | 10x6.5x3 cm

Inner box: 12 pcs
Outer carton: 144 pcs



Dish 6.75"x2.75" | 17x7cm

Inner box: 12 pcs
Outer carton: 96 pcs



Dish 5.5"x3" | 14x7.5 cm

Inner box: 12 pcs
Outer carton: 96 pcs



Dish 5.25"x3.5" | 13x9 cm

Inner box: 12 pcs
Outer carton: 96 pcs



Dish 4" | 10 cm

Inner box: 6 pcs
Outer carton: 144 pcs



Dish 4.5"x2.75" | 11.5x7 cm

Inner box: 6 pcs
Outer carton: 72 pcs



Dish 5.5" | 14 cm

Inner box: 3 pcs
Outer carton: 36 pcs



Bowl 7.75" | 19.5 cm
22 fl oz | 650 ml

Inner box: 3 pcs
Outer carton: 24 pcs





Vase 9"x3.25" | 23x8 cm

Inner box: 1 pc
Outer carton: 12 pcs
5105260919610891



Vase 7.75"x3.25" | 20x8 cm

Inner box: 1 pc
Outer carton: 18 pcs
5105260919610721



Dish 3" | 7.5 cm

Inner box: 12 pcs
Outer carton: 288 pcs
5105260919260711



Bowl 4.25" | 11 cm
7 fl oz | 210 ml

Inner box: 6 pcs
Outer carton: 96 pcs
5105260919261251



Bowl
6" | 15 cm, 15 fl oz | 440 ml

Inner box: 6 pcs
Outer carton: 36 pcs
5105260919249301



Bowl
5" | 13 cm, 9 fl oz | 280 ml

Inner box: 6 pcs
Outer carton: 48 pcs
5105260919249231



Dish 3" | 7.5 cm

Inner box: 12 pcs
Outer carton: 288 pcs
5105260919260641



Dish 3" | 7.5 cm

Inner box: 12 pcs
Outer carton: 288 pcs
5105260919260881



Snack Dish
3.5"x2.5" | 8.5x6 cm

Inner box: 12 pcs
Outer carton: 288 pcs
5105260919260951



Dessert Dish
4"x2" | 10x5 cm, 6 fl oz | 180 ml

Inner box: 6 pcs
Outer carton: 72 pcs
5105260919609521



Snack Dish 4"x1.5" | 10x4 cm

Inner box: 12 pcs
Outer carton: 288 pcs
5105260919271841



Soy Dish
3.25"x3.25" | 8.5x8.5 cm

Inner box: 12 pcs
Outer carton: 144 pcs
5105260919609501



Divided Soy Dish 3.5" | 9 cm

Inner box: 12 pcs
Outer carton: 144 pcs
5105260919604951



Snack Dish 4"x2" | 10.5x5 cm

Inner box: 12 pcs
Outer carton: 288 pcs
5105260919266751



Lid 3.75" | 9.5 cm

Inner box: 12 pcs
Outer carton: 144 pcs
5105260919613791



Vase 5.5" | 14 cm

Inner box: 3 pcs
Outer carton: 24 pcs
5105260919615841



Dessert Vase
4.5"x3" | 11x8 cm, 14 fl oz | 420 ml

Inner box: 1 pc
Outer carton: 24 pcs
5105260919500691



Mini Tagine 4"x4" | 10x10 cm

Inner box: 6 pcs
Outer carton: 48 pcs
5105260919272691

NEW



Divided Triangular Dish
11.5" | 29 cm

Inner box: 3 pcs
Outer carton: 18 pcs
510526091925869



Divided Triangular Dish
9.5" | 24 cm

Inner box: 3 pcs
Outer carton: 24 pcs
510526091925852



Divided Triangular Dish
8" | 20 cm

Inner box: 6 pcs
Outer carton: 36 pcs
510526091925845



Divided Dish 10" | 25.5 cm

Inner box: 4 pcs
Outer carton: 24 pcs
510526091920192



Divided Dish 12.5" | 31.5 cm

Inner box: 3 pcs
Outer carton: 18 pcs
510526091924886



Divided Dish 10" | 25.5 cm

Inner box: 3 pcs
Outer carton: 18 pcs
510526091926910



Round Platter 10" | 25.5 cm

Inner box: 2 pcs
Outer carton: 12 pcs
510526091926583



Divided Square Dish
10.5"x10.5" | 26x26 cm

Inner box: 3 pcs
Outer carton: 12 pcs
510526091927762

NEW



Dish 12.5"x8" | 32x20 cm

Inner box: 3 pcs
Outer carton: 18 pcs
510526091925944



Dish 10.5"x6.5" | 26.5x16.5 cm

Inner box: 3 pcs
Outer carton: 24 pcs
510526091925937



Dish 8.5"x5.5" | 22x14 cm

Inner box: 6 pcs
Outer carton: 36 pcs
510526091925920



Divided Dish 12" | 30 cm

Inner box: 2 pcs
Outer carton: 12 pcs
510526091925975



Divided Dish 12"x3.25"x1.5" | 30x8x4 cm

Inner box: 3 pcs
Outer carton: 24 pcs
510526091926026



Divided Dish 10.25"x3.75"x2" | 26x9.5x5 cm

Inner box: 3 pcs
Outer carton: 24 pcs
510526091926019



Divided Dish 7"x3.75"x2" | 18x9.5x5 cm

Inner box: 6 pcs
Outer carton: 48 pcs
510526091926002



Divided Dish
10" | 25.5 cm

Inner box: 4 pcs
Outer carton: 24 pcs
510526091927726



Divided Dish
7" | 18 cm

Inner box: 6 pcs
Outer carton: 48 pcs
510526091926149




Divided Dish
8.5"x8.5" | 22x22 cm

Inner box: 3 pcs
Outer carton: 18 pcs
510526091926491

NEW



Divided Square Dish
8"x8" | 20x20 cm



Divided Square Dish
6"x6" | 15x15 cm

Inner box: 3 pcs
Outer carton: 18 pcs
5105260919201851

Inner box: 6 pcs
Outer carton: 36 pcs
5105260919201781



Dish 10"x5.5" | 25x14 cm



Dish 8"x4.5" | 20x11.5 cm

Inner box: 3 pcs
Outer carton: 24 pcs
5105260919259061

Inner box: 6 pcs
Outer carton: 48 pcs
5105260919258901



Divided Dish 14.5" | 37 cm



Divided Dish 9" | 23 cm



Divided Dish 5" | 13 cm

Inner box: 3 pcs
Outer carton: 18 pcs
5105260919241691

Inner box: 3 pcs
Outer carton: 24 pcs
5105260919248791

Inner box: 6 pcs
Outer carton: 72 pcs
5105260919259991



Platter 12"x8" | 30x20 cm



Divided Dish 6"x2.5" | 15x6 cm



Divided Dish 5.5"x3" | 14.5x7.5 cm

Inner box: 3 pcs
Outer carton: 18 pcs
5105260919259821

Inner box: 6 pcs
Outer carton: 96 pcs
5105260919275351

Inner box: 6 pcs
Outer carton: 72 pcs
5105260919241521



Dish
7.5"x4.5"x2" | 18.5x11x5 cm



Dish
6"x3.5"x2" | 15x9x4.5 cm

Dish
5"x3"x1.5" | 12.5x7.5x3.5 cm

Inner box: 6 pcs
Outer carton: 48 pcs
5105260919257081

Inner box: 6 pcs
Outer carton: 72 pcs
5105260919257151

Inner box: 6 pcs
Outer carton: 96 pcs
5105260919257221



Napkin Holder
4.5"x2.75" | 11.5x7 cm

Inner box: 6 pcs
Outer carton: 48 pcs



Chopstick Rest

Inner box: 24 pcs
Outer carton: 288 pcs



Chopstick Rest

Inner box: 24 pcs
Outer carton: 288 pcs



Chopstick Rest

Inner box: 24 pcs
Outer carton: 288 pcs



Chopstick Rest

Inner box: 12 pcs
Outer carton: 144 pcs



Napkin Holder
4.5"x3" | 11x8 cm

Inner box: 6 pcs
Outer carton: 48 pcs



Salt & Pepper Set

Inner box: 12 pcs
Outer carton: 288 pcs



Salt & Pepper Set

Inner box: 12 pcs
Outer carton: 288 pcs



Salt & Pepper Set

Inner box: 2 sets
Outer carton: 36 sets



Inner box: 1 set
Outer carton: 36 sets



Salt & Pepper Set

Inner box: 2 sets
Outer carton: 48 sets



Salt Shaker

Inner box: 4 pcs
Outer carton: 144 pcs



Pepper Shaker

Inner box: 4 pcs
Outer carton: 144 pcs



Salt & Pepper Set

Inner box: 4 sets
Outer carton: 72 sets



Salt & Pepper Set

Inner box: 2 sets
Outer carton: 36 sets



Inner box: 1 set
Outer carton: 36 sets



Toothpick Holder

Inner box: 4 pcs
Outer carton: 96 pcs



Salt Shaker

Inner box: 4 pcs
Outer carton: 144 pcs



Pepper Shaker

Inner box: 4 pcs
Outer carton: 144 pcs



Salt & Pepper Set

Inner box: 4 sets
Outer carton: 72 sets



Salt & Pepper Set

Inner box: 2 sets
Outer carton: 24 sets



Toothpick Holder
1.5"x2" | 4x5 cm

Inner box: 12 pcs
Outer carton: 144 pcs



Egg Cup
1.75"x2" | 4.5x5.5 cm

Inner box: 12 pcs
Outer carton: 144 pcs



Egg Cup
2"x2.5" | 5x6.5 cm

Inner box: 6 pcs
Outer carton: 144 pcs



Egg Cup
5"x3.5" | 12.5x9 cm

Inner box: 6 pcs
Outer carton: 96 pcs





Sauce Boat 14 fl oz | 400 ml

Sauce Boat 8 fl oz | 230 ml

Sauce Boat 3 fl oz | 100 ml


Inner box: 4 pcs
Outer carton: 48 pcs



Inner box: 6 pcs
Outer carton: 72 pcs



Inner box: 6 pcs
Outer carton: 96 pcs



Sauce Boat 6 fl oz | 170 ml

Sauce Boat 4 fl oz | 120 ml

Sauce Boat 3 fl oz | 75 ml

Inner box: 4 pcs
Outer carton: 48 pcs




Inner box: 6 pcs
Outer carton: 72 pcs




Inner box: 6 pcs
Outer carton: 96 pcs



Dish 2.75" | 7 cm



Dish 2.75" | 7 cm



Dish 3" | 7.5 cm



Dish 2.25" | 6 cm

Inner box: 6 pcs
Outer carton: 144 pcs



Inner box: 12 pcs
Outer carton: 144 pcs



Inner box: 12 pcs
Outer carton: 144 pcs



Inner box: 24 pcs
Outer carton: 288 pcs



4 fl oz | 130 ml
Mustard Pot with Spoon



Sauce Dish 3.5"x2.5" | 9x6 cm



Dish 3.5"x3.5" | 8.5x8.5 cm



Dish 2.75"x2.75" | 7x7 cm

Inner box: 6 pcs
Outer carton: 72 pcs




Inner box: 6 pcs
Outer carton: 144 pcs



Inner box: 12 pcs
Outer carton: 144 pcs



Inner box: 12 pcs
Outer carton: 288 pcs




Napkin Ring



Soy Dish 3" | 7.5 cm



Soy Dish 4" | 10 cm



Sauce Dish
3"x2.5" | 8 x 6 cm

Inner box: 12 pcs
Outer carton: 144 pcs



Inner box: 24 pcs
Outer carton: 144 pcs



Inner box: 12 pcs
Outer carton: 144 pcs



Inner box: 6 pcs
Outer carton: 144 pcs





Bowl
5" | 12.5 cm, 6 fl oz | 190 ml

Bowl
4" | 10.5 cm, 3 fl oz | 100 ml



Snack Dish 3.25"x2" | 8x5 cm



Snail Dish 5.5" | 14 cm

Inner box: 12 pcs
Outer carton: 72 pcs
5105260919236431

Inner box: 12 pcs
Outer carton: 72 pcs
5105260919248621

Inner box: 12 pcs
Outer carton: 288 pcs
5105260919271911

Inner box: 3 pcs
Outer carton: 36 pcs
5105260919613861



Square Dish 4.75"x4.5"x2.5" | 12x11x6 cm
11 fl oz | 330 ml

Square Dish 4"x3.75"x2" | 10x9.5x5 cm
5 fl oz | 150 ml



Snack Dish
3"x3" | 7.5x7.5 cm



Snack Dish 3.5"x2.25" | 9x6 cm

Inner box: 6 pcs
Outer carton: 72 pcs
5105260919261181

Inner box: 6 pcs
Outer carton: 96 pcs
5105260919261011

Inner box: 6 pcs
Outer carton: 144 pcs
5105260919260401

Inner box: 12 pcs
Outer carton: 144 pcs
5105260919277191



Square Dish 4.25"x4.25"x1.75" | 11x11x4.5 cm
8 fl oz | 250 ml

Square Dish 3.75"x3.75"x1.5" | 9.5x9.5x4 cm
5 fl oz | 150 ml

Square Dish 3"x3"x1.25" | 7.5x7.5x3.5 cm
3 fl oz | 90 ml



Snack/Dessert Dish 4"x3"x1.5" | 10x7x4 cm
3 fl oz | 100 ml

Inner box: 6 pcs
Outer carton: 48 pcs
5105260919238721

Inner box: 6 pcs
Outer carton: 48 pcs
5105260919249341

Inner box: 6 pcs
Outer carton: 72 pcs
5105260919254631

Inner box: 6 pcs
Outer carton: 72 pcs
5105260919610411



Tray 14"x 5" | 36x13 cm

Tray 9.5"x3.5" | 25x8.5 cm



Snack Dish
5" | 12.5 cm, 3 fl oz | 100 ml

Inner box: 4 pcs
Outer carton: 24 pcs
5105260919242681

Inner box: 6 pcs
Outer carton: 48 pcs
5105260919266991

Inner box: 6 pcs
Outer carton: 72 pcs
5105260919249091



Tray
14"x 5" | 35x12 cm


Tray
10"x3.5" | 26x9 cm

Inner box: 4 pcs
Outer carton: 24 pcs
5105260919248931

Inner box: 6 pcs
Outer carton: 48 pcs
5105260919259131



NEW




Shell Dish 24.75"x9.5" | 63x24 cm

Inner box: 1 pc
Outer carton: 8 pcs
510526091928082



Shell Dish 21.75"x8" | 55.5x20.5 cm

Inner box: 2 pcs
Outer carton: 12 pcs
510526091928075



Shell Dish 18.75"x7.25" | 48x18 cm

Inner box: 3 pcs
Outer carton: 18 pcs
510526091928068



Shell Dish 10" | 25.5 cm

Inner box: 4 pcs
Outer carton: 24 pcs
510526091920147



Shell Dish 8" | 20 cm

Inner box: 6 pcs
Outer carton: 36 pcs
510526091920130



Shell Dish 7" | 18 cm

Inner box: 6 pcs
Outer carton: 48 pcs
510526091920123



Shell Dish 6" | 15 cm

Inner box: 12 pcs
Outer carton: 48 pcs
510526091920116



Shell Dish 5" | 13 cm

Inner box: 12 pcs
Outer carton: 96 pcs
510526091920109



Shell Dish 11.5"x11" | 28.5x28 cm

Inner box: 2 pcs
Outer carton: 12 pcs
510526091925883



Shell Dish 9.5"x8.5" | 23.5x22 cm

Inner box: 3 pcs
Outer carton: 24 pcs
510526091925876



Fish Plate 18" | 46 cm

Inner box: 3 pcs
Outer carton: 18 pcs
510526091920093



Fish Plate 13" | 33 cm

Inner box: 3 pcs
Outer carton: 24 pcs
510526091920086



Fish Plate 10" | 25.5 cm

Inner box: 6 pcs
Outer carton: 36 pcs
510526091920079



Fish Plate 8.5" | 22 cm

Inner box: 6 pcs
Outer carton: 48 pcs
510526091920062



Baking Dish 12" | 30 cm

Inner box: 3 pcs
Outer carton: 24 pcs
510526091970128



Baking Dish 10" | 25.5 cm

Inner box: 3 pcs
Outer carton: 18 pcs
510526091970111



Baking Dish 8" | 20 cm

Inner box: 6 pcs
Outer carton: 72 pcs
510526091970104



Baking Dish 8" | 20 cm

Inner box: 6 pcs
Outer carton: 48 pcs
510526091970081



Vase 2.5"x6.5" | 6.5x16.5 cm

Vase 2.5"x6.25" | 6.5x15.5 cm

Vase 3"x5.25" | 7.5x13.5 cm

Vase 3.5"x5.5" | 9x14 cm

Oil/Vinegar Bottle
8 fl oz | 230 ml

Inner box: 6 pcs
Outer carton: 72 pcs



Inner box: 6 pcs
Outer carton: 72 pcs



Inner box: 6 pcs
Outer carton: 72 pcs



Inner box: 6 pcs
Outer carton: 72 pcs



Inner box: 6 pcs
Outer carton: 72 pcs



Soy Bottle 5 fl oz | 160 ml

Soy Bottle 6 fl oz | 170 ml

Soy Bottle 4 fl oz | 130 ml

Soy Bottle 6 fl oz | 170 ml

Soy Bottle 4 fl oz | 130 ml

Inner box: 6 pcs
Outer carton: 72 pcs



Inner box: 6 pcs
Outer carton: 96 pcs




Inner box: 6 pcs
Outer carton: 96 pcs



Inner box: 6 pcs
Outer carton: 96 pcs



Inner box: 6 pcs
Outer carton: 96 pcs



Ashtray 4" | 10 cm

Ashtray 3.5" | 9 cm

Multi-use Saucer 6" | 15 cm

Multi-use Saucer 5.5" | 14 cm

Inner box: 6 pcs
Outer carton: 72 pcs




Inner box: 6 pcs
Outer carton: 96 pcs



Inner box: 12 pcs
Outer carton: 96 pcs



Inner box: 12 pcs
Outer carton: 96 pcs



Ashtray 4" | 10 cm

Spoon 5" | 13 cm

Spoon 5.5" | 13.5 cm

Spoon 4" | 10.5 cm

Inner box: 6 pcs
Outer carton: 96 pcs



Inner box: 24 pcs
Outer carton: 288 pcs



Inner box: 24 pcs
Outer carton: 288 pcs



Inner box: 24 pcs
Outer carton: 288 pcs



Butter Dish 7.5"x5"x3.5" | 19x12.5x8.5 cm

Butter Dish 3.5"x2" | 9.5x5.5 cm

Inner box: 1 pc
Outer carton: 36 pcs



Inner box: 1 pc
Outer carton: 36 pcs



Inner box: 6 pcs
Outer carton: 72 pcs





Cake Stand 12"x12"x3.5" | 30x30x9 cm

Inner box: 1 pc
Outer carton: 8 pcs
510544281961332



Cake Stand 11"x11"x3.5" | 28x28x9 cm

Inner box: 1 pc
Outer carton: 8 pcs
510544281961325



Cake Stand 10"x10"x3.5" | 25x25x9 cm

Inner box: 1 pc
Outer carton: 8 pcs
510544281961318



Bread Vase 9" | 23 cm

Inner box: 2 pcs
Outer carton: 24 pcs
510526091960112



Cake Stand 12"x3.5" | 30x9 cm

Inner box: 1 pc
Outer carton: 8 pcs
510544281961301



Cake Stand 11"x3.5" | 28.5x9 cm

Inner box: 1 pc
Outer carton: 8 pcs
510544281961295



Cake Stand 10"x3.5" | 25x9 cm

Inner box: 1 pc
Outer carton: 8 pcs
510544281961288



Fruit Vase 9.5"x4.5" | 24x11.5 cm

Inner box: 1 pc
Outer carton: 8 pcs
510544281961264



Snack/Dessert Dish
3.5" | 9 cm, 4 fl oz | 130 ml

Inner box: 12 pcs
Outer carton: 144 pcs
510526091960349



Ramekin 3.5"x2.5" | 8.5x6.5 cm, 9 fl oz | 260 ml

Inner box: 6 pcs
Outer carton: 48 pcs
510544281961219

Set of 2 pcs
Outer carton: 24 sets
510526091961256



Ramekin, Set of 3 pcs
3.5"x1.5" | 9x4 cm, 4"x2" | 10.5x5 cm, 4.5"x2" | 12x5.5 cm



Ramekin 6 fl oz | 180 ml
3.5"x1.5" | 9x4 cm



Ramekin 9 fl oz | 270 ml
4"x2" | 10.5x5 cm



Ramekin 14 fl oz | 400 ml
4.5"x2" | 12x5.5 cm

Inner box: 1 set
Outer carton: 24 sets
510526091961225

Inner box: 6 pcs
Outer carton: 96 pcs
510526091961348

Inner box: 6 pcs
Outer carton: 72 pcs
510526091961355

Inner box: 6 pcs
Outer carton: 48 pcs
510526091961362



Lid for Main Course
8" | 20.5 cm

Inner box: 4 pcs
Outer carton: 24 pcs
510526091960099



Lid for Main Course
7" | 17.5 cm

Inner box: 4 pcs
Outer carton: 24 pcs
510526091960082



Lid for Main Course
5" | 12.5 cm

Inner box: 6 pcs
Outer carton: 36 pcs
510526091960075

NEW



Baking Dish with Handles
12"x9.75"x2.75" | 30.5x25x7 cm, 88 fl oz | 2600 ml

Inner box: 1 pc
Outer carton: 12 pcs
510544281970266



Baking Dish with Handles
9.75"x8"x2.25" | 25x20x6 cm, 45 fl oz | 1330 ml

Inner box: 1 pc
Outer carton: 12 pcs
510544281970259



Baking Dish with Handles
8"x6.5"x2" | 20.5x16.5x5 cm, 26 fl oz | 780 ml

Inner box: 2 pcs
Outer carton: 24 pcs
510544281970242

Inner box: 1 pc
Outer carton: 24 pcs
510526091970241

NEW



Baking Dish with Handles
13.25"x8.5"x2.75" | 34x21.5x7 cm, 86 fl oz | 2560 ml

Inner box: 1 pc
Outer carton: 12 pcs
510544281970204

Inner box: 1 pc
Outer carton: 12 pcs
510526091970203



Baking Dish with Handles
11.25"x7"x2.25" | 28.5x18x6 cm, 56 fl oz | 1650 ml

Inner box: 1 pc
Outer carton: 12 pcs
510544281970198

Inner box: 1 pc
Outer carton: 12 pcs
510526091970197



Baking Dish with Handles
9"x5.75"x2" | 23x14.5x5 cm, 29 fl oz | 860 ml

Inner box: 2 pcs
Outer carton: 24 pcs
510544281970181

Inner box: 1 pc
Outer carton: 24 pcs
510526091970180

NEW



Baking Dish with Handles
12"x10.25"x2.75" | 30.5x26x7 cm, 78 fl oz | 2320 ml

Inner box: 1 pc
Outer carton: 12 pcs
510544281970235

Inner box: 1 pc
Outer carton: 12 pcs
510526091970234



Baking Dish with Handles
10"x8.5"x2.25" | 25.5x21.5x5.5 cm, 43 fl oz | 1280 ml

Inner box: 1 pc
Outer carton: 12 pcs
510544281970228

Inner box: 1 pc
Outer carton: 12 pcs
510526091970227



Baking Dish with Handles
8"x6.75"x2" | 20.5x17x5 cm, 22 fl oz | 650 ml

Inner box: 2 pcs
Outer carton: 24 pcs
510544281970211

Inner box: 1 pc
Outer carton: 24 pcs
510526091970210

NEW



Baking Dish with Handles
14.25"x9.25"x2.75" | 36x23.5x7 cm, 89 fl oz | 2640 ml

Inner box: 1 pc
Outer carton: 12 pcs
510544281970297

Inner box: 1 pc
Outer carton: 12 pcs
510526091970296



Baking Dish with Handles
12"x7.75"x2.25" | 30.5x19.5x6 cm, 53 fl oz | 1570 ml

Inner box: 1 pc
Outer carton: 12 pcs
510544281970280

Inner box: 1 pc
Outer carton: 12 pcs
510526091970279



Baking Dish with Handles
10.25"x6.75"x2" | 26x17x5 cm, 33 fl oz | 990 ml

Inner box: 2 pcs
Outer carton: 24 pcs
510544281970273

Inner box: 1 pc
Outer carton: 24 pcs
510526091970272



Baking Dish 8.5" | 22 cm

Inner box: 3 pcs
Outer carton: 36 pcs
510526091970098



Baking Dish with Handles
6"x3.75" | 15x9.5 cm

Inner box: 6 pcs
Outer carton: 48 pcs
510526091970173



Baking Dish with Handle
6" | 15 cm, 15 fl oz | 450 ml

Inner box: 3 pcs
Outer carton: 36 pcs
510526091970135



Baking Dish with Handle
5" | 13 cm, 10 fl oz | 300 ml

Inner box: 3 pcs
Outer carton: 36 pcs
510526091970142

NEW



Baking Dish with Handles
11.75"x9.5"x2.75" | 30x24.5x7 cm, 83 fl oz | 2450 ml

Inner box: 1 pc
Outer carton: 12 pcs



Baking Dish with Handles
10"x8.25"x2.5" | 25.5x21x6.5 cm, 53 fl oz | 1560 ml

Inner box: 1 pc
Outer carton: 12 pcs



Baking Dish with Handles
8.25"x6.5"x2.25" | 20.5x16.5x5.5 cm, 28 fl oz | 830 ml

Inner box: 2 pcs
Outer carton: 24 pcs



Inner box: 1 pc
Outer carton: 24 pcs



NEW



Baking Dish with Handles
12.75"x8.25"x2.75" | 32.5x21x7 cm, 85 fl oz | 2500 ml

Inner box: 1 pc
Outer carton: 12 pcs



Inner box: 1 pc
Outer carton: 12 pcs



Baking Dish with Handles
10.75"x6.75"x2.25" | 27.5x17.5x6 cm, 46 fl oz | 1370 ml

Inner box: 1 pc
Outer carton: 12 pcs



Inner box: 1 pc
Outer carton: 12 pcs



Baking Dish with Handles
8.75"x5.5"x2" | 22.5x14x5 cm, 25 fl oz | 740 ml

Inner box: 2 pcs
Outer carton: 24 pcs



Inner box: 1 pc
Outer carton: 24 pcs



NEW



Baking Dish with Handles
7.5"x6.25"x3" | 19x16x7.5 cm, 31 fl oz | 910 ml

Inner box: 2 pcs
Outer carton: 24 pcs



Inner box: 1 pc
Outer carton: 24 pcs



Baking Dish with Handles
6"x5"x2.5" | 15.5x13x6.5 cm, 17 fl oz | 510 ml

Inner box: 2 pcs
Outer carton: 48 pcs



Inner box: 1 pc
Outer carton: 48 pcs



Baking Dish with Handles
4.75"x3.75"x2" | 12x10x5 cm, 7 fl oz | 220 ml

Inner box: 2 pcs
Outer carton: 72 pcs



Inner box: 1 pc
Outer carton: 72 pcs



NEW



Baking Dish with Handles
13.75"x9.5"x3" | 35x24x7.5 cm, 92 fl oz | 2730 ml

Inner box: 1 pc
Outer carton: 12 pcs



Inner box: 1 pc
Outer carton: 12 pcs



Baking Dish with Handles
11.5"x8"x2.5" | 29.5x20.5x6 cm, 56 fl oz | 1650 ml

Inner box: 1 pc
Outer carton: 12 pcs



Inner box: 1 pc
Outer carton: 12 pcs



Baking Dish with Handles
10.25"x7"x2.25" | 26x18x5.5 cm, 34 fl oz | 1000 ml

Inner box: 2 pcs
Outer carton: 24 pcs



Inner box: 1 pc
Outer carton: 24 pcs



Baking Dish 10" | 25.5 cm

Inner box: 4 pcs
Outer carton: 24 pcs



Baking Dish 9" | 23 cm

Inner box: 4 pcs
Outer carton: 24 pcs



Baking Dish 8" | 20 cm

Inner box: 6 pcs
Outer carton: 36 pcs



NEW



Baking Dish with Handles
12.5"x8.5"x2.75" | 32x21.5x7 cm, 72 fl oz | 2130 ml

Inner box: 1 pc
Outer carton: 12 pcs



Inner box: 1 pc
Outer carton: 12 pcs



Baking Dish with Handles
10.5"x7"x2.25" | 27x17.5x6 cm, 42 fl oz | 1230 ml

Inner box: 1 pc
Outer carton: 12 pcs



Inner box: 1 pc
Outer carton: 12 pcs



Baking Dish with Handles
7.75"x5.75"x2" | 22x14.5x5 cm, 22 fl oz | 660 ml

Inner box: 2 pcs
Outer carton: 24 pcs



Inner box: 1 pc
Outer carton: 24 pcs



Baking Dish with Handles
12.5"x8.5"x2.75" | 32x21.5x7 cm, 75 fl oz | 2220 ml

Inner box: 1 pc
Outer carton: 12 pcs



Inner box: 1 pc
Outer carton: 12 pcs



Baking Dish with Handles
10.5"x7"x2.25" | 27x17.5x6 cm, 44 fl oz | 1300 ml

Inner box: 1 pc
Outer carton: 12 pcs



Inner box: 1 pc
Outer carton: 12 pcs



Baking Dish with Handles
8.75"x5.5"x2" | 22x14x5 cm, 24 fl oz | 700 ml

Inner box: 2 pcs
Outer carton: 24 pcs



Inner box: 1 pc
Outer carton: 24 pcs



NEW

NEW

NEW

NEW



Baking Dish with Handles
12"x9.75"x2.75" | 30.5x24.5x7 cm, 69 fl oz | 2050 ml

Inner box: 1 pc
Outer carton: 12 pcs



Inner box: 1 pc
Outer carton: 12 pcs



Baking Dish with Handles
10"x8"x2.25" | 25.5x20.5x6 cm, 37 fl oz | 1080 ml

Inner box: 1 pc
Outer carton: 12 pcs



Inner box: 1 pc
Outer carton: 12 pcs



Baking Dish with Handles
8"x6.25"x2" | 20.5x16x5 cm, 20 fl oz | 600 ml

Inner box: 2 pcs
Outer carton: 24 pcs



Inner box: 1 pc
Outer carton: 24 pcs



Baking Dish with Handles
14.25"x9"x2.5" | 36x22.5x6 cm, 70 fl oz | 2080 ml

Inner box: 1 pc
Outer carton: 12 pcs



Inner box: 1 pc
Outer carton: 12 pcs



Baking Dish with Handles
11.75"x7"x2.25" | 29.5x18x5.5 cm, 40 fl oz | 1170 ml

Inner box: 1 pc
Outer carton: 12 pcs



Inner box: 1 pc
Outer carton: 12 pcs



Baking Dish with Handles
10.5"x6.5"x2" | 27x16.5x5 cm, 30 fl oz | 900 ml

Inner box: 2 pcs
Outer carton: 24 pcs



Inner box: 1 pc
Outer carton: 24 pcs



Baking Pot 21 fl oz | 620 ml

Inner box: 2 pcs
Outer carton: 24 pcs



Inner box: 1 pc
Outer carton: 24 pcs



Inner box: 2 pcs
Outer carton: 24 pcs



Inner box: 1 pc
Outer carton: 24 pcs



Baking Pot 19 fl oz | 550 ml



Baking Pot 15 fl oz | 450 ml

Inner box: 3 pcs
Outer carton: 36 pcs



Baking Pot 12 fl oz | 350 ml

Inner box: 3 pcs
Outer carton: 36 pcs



A, AB, SP
BROWN BOX
WL-996109/A



 **C**
COLOUR BOX
WL-996109/1C

