




- COMPONENT LIST**
- F1 : Fuse
 - K1 : Tank Heater Contactor
 - K2-K2A : Boiler Heater Contactor
 - P : Solenoid Valve (Water Supply)
 - M1 : Washing Pump
 - M2 : Rinsing Pump
 - M3 : Drain Pump
 - M4 : Detergent Pump
 - M5 : Rinse Aid Pump
 - RB : Boiler Resistance
 - RT : Tank Resistance
 - S1 : Door Switch
 - S2 : Tank NTC Probe
 - S3 : Boiler NTC Probe
 - S4 : Water Level
 - S5 : Boiler Limit Thermostat
 - S6 : Tank Limit Thermostat

