




EXPLODED VIEW


AMS1 P

Apach
COOK *line*









SPARE PARTS

POS.	DESCRIPTION	AMS1 P	AMS2 P	AMS1 ECO P	AMS2 ECO P
1	Door handle	5M200020	5M200020	5M200020	5M200020
2	Handle plate	4P100180	4P100180	4P100031	4P100031
3	Right door plate	4P100182	4P100182	4P100041	4P100041
4	Front door	/	/	4P050046	4P050046
4A	Top/bottom door part	4P050280	4P050280	/	/
4B	Left/reght door part	4P050281	4P050281	/	/
5	Counter door	4C020094	4C020094	4C020046	4C020046
6	Door glass	5V010015	5V010015	/	/
7	Door gasket	5G100065	5G100065	/	/
8	Handle screw	5V500102	5V500102	5V500102	5V500102
9	Door screw	5V500499	5V500499	5V500499	5V500499
10	Door rotation screw	5V500060	5V500060	5V500060	5V500060
11	Door plate screw	5V500063	5V500063	5V500063	5V500063
12	Refractory stone	5P050100	5P050100	5P050100	5P050100
13	Heating element	5R050090	5R050090	5R050090	5R050090
14	Timer	/	/	5T010302	5T010302
15	Thermostat	5T010005	5T010005	5T010005	5T010005
16	Thermostat knob	5M200006	5M200006	5M200006	5M200006
17	Resistance light	5L020017	5L020017	5L020017	5L020017
18	General switch	5I100016	5I100016	5I100016	5I100016
19	Command label	5E206597	5E206598	5E206680	5E206681
20	Thermostat/timer screw	5V500012	5V500012	5V500012	5V500012
21	Bulb	5L020005	5L020005	5L020005	5L020005
22	Lamp glass	5V010003	5V010003	5V010003	5V010003
23	Terminal block	5M100005	5M100005	5M100005	5M100005
24	Terminal block screw	5V500012	5V500012	5V500012	5V500012
25	Foot	5P020030	5P020030	5P020030	5P020030
26	Foot screw	5V500220	5V500220	5V500220	5V500220
27	Upper shell	4S030085	4S030086	4S030085	4S030086
28	Shell screw	5V500502	5V500502	5V500502	5V500502
29	Shell screw	5V500498	5V500498	5V500498	5V500498
32	Cable gland	5P100002	5P100002	5P100002	5P100002
33	Timer knob	/	/	5M200005	5M200005
D	Complete door	7A010085	7A010085	7A010101	7A010101
L	Complete lamp	7P010200	7P010200	7P010200	7P010200