


ПЕЧЬ ДЛЯ ПИЦЦЫ TATRA PRO 44



ПЕЧЬ ДЛЯ ПИЦЦЫ TATRA TPO 44

1	Housing	E072203
2	Side Panel	E072209
3	Left Cover	E072204
4	Door Frame	E070008
8	Door complete	E070001
9	Panel	E072206
10	Base	E070013
21	Bracket for Thermostat	E050121
23	Bracket for Thermostat	E050123
25	Fixing for Heating Element	E050126
30	Heating Element (Upper and Lower front ones) 1150 W	CP700-1150WHE
30.A	Heating Element (Upper and Lower front ones) 1350 W	CP700-1350WHE
31	Knob, black-chromed for thermostat	EOANOT235
32	Green indicator Light,complete	043828
33	Thermostat 455°C	OT45SEGO
34	Refracter Stone(Italian)	CP700-700.355
35	Handle with connect part, big	EOBK600N
37	Connector, 2-poles, ceramic for lamp	CRMO057KLMS
39	Lamp On/Off Switch	A040588
40	Control Panel Sticker	EOQ15ETKT
41	Door glass	E049371
47	Thermometer	E000521506
48	Bracket for heating element	E070099
	Halogen Lamp w.cover glass, square	EO15ELCSQ
49	Halogen Bulb G9	06061056
51	Therminal box	T00133BX
52	Connector with 2 poles	E073071
53	Connector with 3 poles	E0730733
54	Strain Relief PG21	010578030