




LEGEND		XF085
1	VT090	156 2H070
2	VT091	157 2H469
3	2B111	158 GR312
4	2B112	159 OG017
5	OB110	161 KH071
6	OB119	163 2H555
19	VE086	165 OH318
22	2H060	166 GR320
23	2H061	170 GR035
24	MG119	171 GN060
25	CR070	172 VE028
26	CR100	173 GN192
41	MN120	174 VE027
43	MN041	195 6F018
46	MN042	196 OH057
48	TM011	197 6H024
50	TR006	198 2D017
51	TM012	
52	VE177	
53	VE162	
54	VE161	
56	VE165	
57	VE166	
58	VE164	
60	VE175	
66	VE169	
68	2A0017	
89	VN032	
90	VE221	
91	OH296	
92	PD020	
95	CE119	
111	VN026	
112	OH511	
113	6H022	
114	GN034	
115	VN041	
116	GN224	
117	RS026	
133	EL029	
134	EL022	
136	RC500	
138	TB040	
139	TR250	
140	VM250	
143	2E017	
144	PD031	

DIS.:ESPLOSO	DATA
EXPLODED VIEW	
MOD: XF085 ELENA MANUAL	12/07/2000
FILE	
F085X01B	
	UNOX OVENS PLANET

12 JUL 2000

