


**/// BRAVIOR[®]
BONAMAT**

Operating instructions
Photos

ROUND FILTER COFFEE BREWER




B-series

700.403.800


	English	Türkçe	Русский	Español	中国語	韓国語	베트남어
1.	 Use	Kullanım	Использование	Uso	使用	使用	使用
	 Dripping	Damlama	Капание	Goteo	滴水	滴水	滴水
2.	 Cleaning, frequently	Temizleme, sık sık	Очистка, регулярно	Limpieza frecuente	清洗	频繁的清洗	清潔・次數
	 Wait	Bekleme	Ожидание	Espera	お待ちください	等待	等候
	 Acoustic signal	Sesli sinyal	Звуковой сигнал	Señal acústico	音信号	선호음	聽覺信號
3.	 Descaling	Kireçten Arındırma	Удаление накипи	Descalificar	スケール除去	스케일 제거	清除水垢
	 Read Operating Instructions	Kullanma Talimatini Oku	Чтение инструкции в системе горячей воды	Lea instrucciones de uso	取扱説明書参照	취급설명서 참조	閱讀操作說明
4.	 Initial use	İlk kullanım	Первое использование	Uso inicial	使い初め	사용 초기	初次使用
5.	Programming (operator)	Programlama (operatör)	Программирование (оператор)	Programación (operador)	(ユーザー)プログラミング	사용자 프로그래밍	程式(操作)
	 Selection keys	Seçme düğmeleri	Выбор клавиш	Tecla de selección	選択ボタン	선택 키	選擇按鍵
	 Confirm	Onayla	Подтвердить	Confirmar	確認	확 정	確定
	 Cancel	Iptal	Отменить	Cancelar	キャンセル	취 소	取消
	 Water hardness	Suyun sertliği	Жесткость воды	Dureza de agua	水硬度	수질 경도	水的硬度
	 Read Operating Instructions	Kullanma Talimatini Oku	Читайте инструкции	Lea instrucciones de uso	取扱説明書参照	취급설명서 참조	閱讀操作說明
6.	Programming (principal)	Programlama (esas)	Программирование (оператор)	Programación (principal)	(主要な)プログラミング	프로그램밍(원리)	程式(主要的)
	 Selection keys	Seçme düğmeleri	Выбор клавиш	Tecla de selección	選択ボタン	선택 키	選擇按鍵
	 Confirm	Onayla	Подтвердить	Confirmar	확인	확 정	確定
	 Cancel	Iptal	Отменить	Cancelar	キャンセル	취 소	取消
	 Off	Kapali	Выключение	Apagado	꺼짐	꺼짐	關閉
	 Min.	En Az	Минимум	Min.	최소	최 소	最小
	 Standard	Standart	Стандарт	Estándar	표준	표준	標準
	 Max.	En Fazla	Максимум	Max.	최대	최 대	最大
	 Water hardness	Suyun sertliği	Жесткость воды	Dureza de agua	水硬度	수질 경도	水的硬度
	 Read Operating Instructions	Kullanma Talimatini Oku	Читайте инструкции	Lea instrucciones de uso	取扱説明書参照	취급설명서 참조	閱讀操作說明
	Hold 10 sec.	10 san. Tut	Держите 10 секунд	Aguante 10 Segundos	10秒待機	10초간 대기	按著10秒
	Select desired time setting (1-14)	Istenilen zaman ayarını sec (1-14)	Выберите нужное время заваривания 1-14	Selecciona tiempo deseado (1-14)	時間設定(1-14)の選択	시간 설정(1-14)의 선택	選擇所需時間設定1-14
7.	Error codes	Arıza Kod	Коды ошибок	Códigos de mal función	エラーコード	에러 코드	錯誤的編號

1. USE (B)





2. CLEANING, FREQUENTLY (B)




















3. DESCALING (B) $\pm$ 30 MIN. (OPERATOR)

















4. INITIAL USE (B)







5. PROGRAMMING (B) (OPERATOR)

 < 5 sec.						= 0	
				§ 3.			
						  	
							
							

6. PROGRAMMING (B) (PRINCIPAL USER)

<		
---	--	--

7. ERROR CODES (B)





/// BRAVILOR[®]
BONAMAT

COFFEE BREWING MACHINES
MACHINES A CAFE
KAFFEEBRUEHMASCHINEN
KOFFIEZETAPPARATEN

© 11-2001

700.403.800